


PARTS LIST

LIGHT BOX




PARTS LIST



ITEM NO	PART NO	DESCRIPTION	QTY
1	07.040.043	Light Box Bracket A-01	1
2		Light Box Bracket A-02	1
3	01.019.232	Top White Light Panel 1	1
4	07.040.044	Top Acrylic B	2
5		Top Acrylic B	2
6	07.040.086	Top Light Panel Hardware	1
7	07.040.085	Top Acrylic B - Clip Strip	2
8		Mirror Top - Clip A	1
9	07.040.045	Top Acrylic Bracket B-01	3
10		Top Acrylic Bracket B-02	3
11	07.040.086	Top Light Panel Hardware	2
12		Top Light Panel Hardware	1
13	07.040.087	Top Light Panel - Base B	1
14	06.050.002	High Five Tickets NO.1	1
15	06.050.004	High Five Tickets NO.2-R	1
16	06.050.007	High Five Tickets NO.6	1
17	06.050.003	High Five Tickets NO.2-L	1

OVERHEAD CRANE (1/2)



PARTS LIST


OVERHEAD CRANE (2/2)



PARTS LIST

ITEM NO	PART NO	DESCRIPTION	QTY
1	01.018.224	Track	1
2	07.040.051	Crane Drive Rod	1
3	07.040.052	Crane Stroke Photoelectric Sensor Bracket	3
4	07.040.053	Crane Photoelectric Sensor Bracket Fixing Part	1
5	07.039.001	57 Motor Bracket	2
6	01.018.224	Track	2
7	01.019.219	Photoelectric Sensor	1
8-13	07.040.046	Crane Beam Fixing Bracket	1
14	07.040.047	Tank Chain Front Photoelectric Sensor Bracket	1
15	07.040.048	Tank Chain Hook Bracket	1
16	07.040.076	Tank Chain Left & Right Fixing Bracket - 01	1
17-18	01.015.072	Tank Chain	1
19	Included in the guide rail		
20-21	01.009.225	Crane Lowering Motor - 2.0MM (Right Wire Outlet)	1
22	07.040.054	Crane Stroke Photoelectric Sensor Plate	1
23-27	07.040.056	Crane Claw Control Box	1
28	07.040.063	Crane Claw Storage Cover	1
29	07.040.068	Pulley Shaft Bracket - 01	2
30	07.040.069	Pulley Shaft Bracket - 02	2
31	07.040.070	Pulley Shaft	2
32	01.021.125	Bearing Wheel	1
33	07.040.071	Crane Claw Control Box Wire Cover	1
34-35	01.009.217	Crane Lowering Motor - 2.0MM (Left Wire Outlet)	1
36	07.040.072	Left & Right Tank Chain Support Bracket - 01	1
37	07.040.064	Crane Fixing Bracket A	1
38	07.040.065	Crane Fixing Bracket B	5
39	07.040.066	Crane Fixing Bracket C	2
40	07.040.067	Crane Fixing Bracket D	2
41	01.018.280	Claw	5
42	06.050.014	Decal NO.13	1
43-44	07.040.100	Crane Shaft Bushing (T-Type A)	2
45	07.040.074	Tank Chain Left & Right Fixing Bracket - 02	1
46	07.040.128	Crane Control Box Cover Plate	1
47	06.050.053	Decal NO.12	1
48-49	01.007.381	Colorful LED Light	15
50	01.019.258	2-Position Figure-8 Plate	2
51	01.019.229	6-Position Figure-8 Plate	2
52	07.040.077	Left & Right Tank Chain Support Bracket - 02	1
56	07.040.099	Crane Shaft Bushing (T-Type B)	2
58	07.040.059	Crane Claw Operating Structure F	2
59	07.040.060	Crane Claw Operating Structure G	2
60	07.040.055	Crane Claw Control Box Fixing Plate	2
61	07.040.075	Side Hooks (Type A)	1
62	07.040.073	Tank Chain Front Fixing Bracket	1
63	07.040.049	Crane Fixing Seat	2
64	07.040.050	Crane Fixing Seat - 01	2
65	07.040.078	Side Hooks (Type B)	1

TURNTABLE




ITEM NO	PART NO	DESCRIPTION	QTY
1	07.040.029	Turntable Base - 03	2
2	07.040.030	Machined Shaft Part A	2
3	07.040.031	Turntable Motor Base	2
4	07.040.032	Turntable Assembly	2
5	07.040.104	Plastic Nylon Pulley - 19	12
6	01.009.249	Motor 56F545 12V 5 RPM	1
7	01.010.260	Left Turntable Blister Part	1
8	01.010.261	Right Turntable Blister Part	1
9	07.040.079	Drilling Seat A	2
10	07.040.080	Drilling Seat BA	2
11	07.040.081	Machined Shaft Part A	4



FRONT DOOR ASSEMBLY




PARTS LIST



ITEM NO	PART NO	DESCRIPTION	QTY
1	07.040.040	Door Panel Assembly	1
2	07.040.103	Spring Latch on Door	1
3	01.017.009	Ticket Dispenser	1
4	01.018.206	Lock	2
5	01.015.002	Fake Coin Slot	1

CONSOLE ASSEMBLY (1/2)



ITEM NO	PART NO	DESCRIPTION	QTY
1	07.040.002	Console Main Frame	1
2	07.040.088	Console Bottom Light Strip Bracket A	1
3	07.040.089	Console Bottom Light Strip Bracket B	2
4	07.040.090	Side Acrylic Fixing Box	2
5	06.050.024	High Five Tickets NO.23	2
6	07.040.003	Coin Acceptor Bracket	1
7	07.040.092	Coin Chute B	1
8	07.040.093	Coin Chute A	1
11	07.040.004	Speaker Fixing Plate	2
12	07.040.005	Speaker Clamping Plate	8
13	07.040.117	Speaker Pad	2
14	07.040.107	8-Inch Speaker PP Cone	4
15	wing nut	wing nut	18
16	01.016.214	4-Inch Speaker	2
17	07.040.108	Speaker PP Cap Dust Cover	4
18	07.040.127	Console Acrylic Supporting Plate	1
19	07.040.007	Coin Slot Mounting Base	1
20	01.008.058	Joystick B	1



PARTS LIST


CONSOLE ASSEMBLY (2/2)

ITEM NO	PART NO	DESCRIPTION	QTY
21	06.050.010	High Five Tickets NO.9-L	1
	06.050.052	High Five Tickets NO.10	1
	06.050.012	High Five Tickets NO.11-R	1
22	06.009.021	LCD Screen	1
23	07.040.102	4-Hole Coin Slot	1
25	07.002.152	Metal Button Coin Return Lever	1
26	07.040.008	Console Connecting Plate	2
27	07.040.040	Door Panel Assembly	1
28	07.040.103	Door Spring Pin	1
29	01.017.009	Ticket Dispenser	1
30	01.018.206	Lock	2
31	01.015.002	Counterfeit Coin Outlet	1
32	01.04.089	Hand-Tightened Screw	5
33	06.050.018	High Five Tickets O.17-L	1
	06.050.019	High Five Tickets NO.18-R	1
34	06.050.026	High Five Tickets NO.25	1
35	01.04.090	M4 Screw	18
36	06.050.043	High Five Tickets NO.42	1
37	07.040.134	Rear Cover	1
38	07.040.091	Card Machine Hardware	1
39	06.050.030	Card Machine Acrylic	1
40	07.040.105	Small Spring Latch	4
41	01.008.056	Play Button	1
42	01.008.063	Illuminated Button	1
43	01.018.198	2.5-Inch Wheel	2



PARTS LIST

KEY ELECTRICAL PARTS



ITEM NO	PART NO	DESCRIPTION	QTY
1	01.005.042	Power Supply LR500WAX6	3
3	01.019.232	Top White Light Board 1	1
4	01.016.251	57 Stepper Motor - Driver	2
5	01.019.231	Light Card	2
6	02.083.001	Motherboard	1
7	01.016.274	RFID Module	1
8	01.016.275	Dedicated Antenna	1

