
















PARTS LIST

CAPSULE CUBE (1/3)






PART NUMBER	PART NAME	DIAGRAM
FLTY-01	Main Board (Capsule)	
FLTY-02	WIFI PCB	
FLTY-03	Prize Sensor Receiver	
FLTY-04	Prize Sensor Transmitter	
FLTY-07	Sensor	
FLTY-08	Lighting Drive PCB	
FLTY-09	Coin Selector Light PCB	
FLND-001	Knob Light PCB	



CAPSULE CUBE (2/3)









PART NUMBER	PART NAME	DIAGRAM
FLTY-10	Mini LCD	
FLTY-12	Set up PCB	
FLND-002	Power Supply (LRS150FC-12)	
FLND-003	Turnable Motor	
FLTY-13	Fan (60x60x15mm/12v)	
FLTY-15	Fan (80x80x25mm/12V)	
FLTY-16	Rocker Switch	
FLTY-17	Speaker (8Ω 5W) 50x90mm	

CAPSULE CUBE (3/3)

PART NUMBER	PART NAME	DIAGRAM
FLTY-18	Meter	
FLND-004	Knob (Rotary Switch)	
FLTY-23	Pole Clamp	
FLTY-24	Side Glass (507*456*5mm)	
FLTY-25	Front Glass (494*372*5mm)	








CRANE CUBE (1/3)

PART NUMBER	PART NAME	DIAGRAM
FLWW-001	Main Board (Crane)	
FLTY-02	WIFI PCB	
FLTY-05	Transmitter	
FLTY-06	Receiver	
FLTY-08	Lighting Drive PCB	
FLTY-09	Coin Selector Light PCB	
FLTY-10	LCD PCB 4"	
FLTY-12	Set up PCB	



CRANE CUBE (2/3)

PART NUMBER	PART NAME	DIAGRAM
FLWW-002	Power Supply (LM150-12B12)	
FLWW-003	Power Supply (LM150-12B24)	
FLTY-13	Fan (60x60x15mm / 12v)	
FLTY-15	Fan (80*80*25 /12V)	
FLTY-16	Rocker Switch	
FLTY-17	Speaker (8Ω 5W) 50x90mm"	
FLTY-18	Meter	
FLTY-19	Start Button	

CRANE CUBE (3/3)

PART NUMBER	PART NAME	DIAGRAM
FLWW-004	Joystick	
FLWW-005	Claw Mechanism	
FLTY-23	Pole Clamp	
FLTY-24	Side Glass (507*456*5mm)	
FLTY-25	Front Glass (494*372*5mm)	

DISPLAY CUBE (1/2)









PART NUMBER	PART NAME	DIAGRAM
FLMC-001	Main Board	
FLTY-02	WIFI PCB	
FLMC-002	LED Controller	
FLMC-003	Power Supply (DC12V, 150W)	
FLMC-004	Power Supply (LM50-20B05)	
FLMC-005	Rocker Switch	
FLTY-14	Fan (60x60x15mm / 12v)	
FLTY-15	Fan (80*80*25 12V)	



DISPLAY CUBE (2/2)

PART NUMBER	PART NAME	DIAGRAM
FLMC-006	Dot Matrix Display (128*256mm)	
FLTY-20	Frame Cover	
FLTY-21	Door Frame Light Module A	
FLTY-22	Door Frame Light Module B	
FLTY-23	Pole Clamp	
FLTY-24	Side Glass (507*456*5mm)	
FLTY-25	Front Glass (494*372*5mm)	

PEG CUBE (1/3)

PART NUMBER	PART NAME	DIAGRAM
FLTY-01	Main Board (Peg)	
FLTY-02	WIFI PCB	
FLJZ-001	Motor Control PCB	
FLTY-05	Transmitter	
FLTY-06	Receiver	
FLTY-08	Lighting Drive PCB	
FLTY-09	Coin Selector Light PCB	
FLJZ-002	Sensor	











PEG CUBE (2/3)

PART NUMBER	PART NAME	DIAGRAM
FLTY-10	LCD PCB (4")	
FLTY-12	Set up PCB	
FLJZ-003	Power Supply (LM150-20B12R2)	
FLJZ-004	Turntable Stepper Motor	
FLJZ-005	Drop Motor	
FLTY-14	Fan (60x60x15mm / 12v)	
FLTY-15	Fan (80*80*25 /12V)	
FLTY-16	Rocker Switch	









PEG CUBE (3/3)

PART NUMBER	PART NAME	DIAGRAM
FLTY-17	Speaker (8Ω 5W) 50x90mm	
FLTY-18	Meter	
FLTY-19	Start Button	
FLJZ-006	Stop Button	
FLTY-23	Pole Clamp	
FLTY-24	Side Glass (507*456*5mm)	
FLTY-25	Front Glass (494*372*5mm)	




ROTARY CUBE (1/3)

PART NUMBER	PART NAME	DIAGRAM
FLTY-01	Main Board (Rotary)	
FLTY-02	WIFI PCB	
FLTY-03	Prize Sensor Receiver	
FLTY-04	Prize Sensor Transmitter	
FLTY-07	Sensor	
FLTY-08	Lighting Drive PCB	
FLTY-09	Coin Selector Light PCB	
FLTY-10	LCD PCB (4")	

ROTARY CUBE (2/3)

PART NUMBER	PART NAME	DIAGRAM
FLTY-12	Set up PCB	
FLSW-001	Power Supply LRS-150-12	
FLSW-002	Turntable Motor	
FLTY-13	Fan (60x60x15mm / 12v)	
FLTY-15	Fan (80*80*25 /12V)	
FLTY-16	Rocker Switch	
FLTY-17	Speaker (8Ω 5W) 50x90mm	
FLTY-18	Meter	

ROTARY CUBE (3/3)

PART NUMBER	PART NAME	DIAGRAM
FLTY-19	Start Button	
FLTY-23	Pole Clamp	
FLTY-24	Side Glass (507*456*5mm)	
FLTY-25	Front Glass (494*372*5mm)	