

Habco Ambient Cooler with Log Procedure

1. Hold the **P** button, wait for the display to show **SP**
2. Press the **Down** button once, the display will show **tCF**
3. Press **P** once then
4. Press the **UP** button repeatedly until the display shows 8 (was 2)
5. Press **P**, the display will return to **tCF**
6. Press and hold the **U** button, The display will change to **rP**
7. Press **P** once, then press and hold the **U** button until you reach **287.**
8. Once you see **287** on the display press **P** once
9. Press the **Down** button repeatedly until you reach **AL**
10. Press **P** once then press the **Down** button to navigate to **AH1**
11. Press **P** once then change the value to 75 (was 41)
12. Press **P** once
13. Hold the **U** button *The display will return to **AL**
 - Hold the **U** button again and the screen will shuttle back to the temperature display

COOLER IS NOW IN AMBIENT MODE.