

INSTRUCTIONS FOR REPLACING HEALTH LOCK LATCH

Below are instructions if maybe the latch on the door is loose or might not be aligned properly with the automatic locking mechanism.

- First check to see if the door latch is loose. If so, remove the two screw caps that reveal the screws that secure the door latch to the door and using a phillips screwdriver to see if it's possible to tighten the screws **(DO NOT OVERTIGHTEN AS THIS WILL STRIP THE SCREW, JUST TIGHTEN TO POINT WHERE THE LATCH IS SECURE AND NOT WIGGLING IN POSITION, AS WELL DO NOT REMOVE BOTH OF THE SCREWS COMPLETELY AS THIS WILL CAUSE THE SLIDING BACKING PLATE TO FALL TO BOTTOM OF DOOR FRAME)**. Please refer to the attached document on manually disabling the HEALTH LOCK, as it will assist you on this process and provide important instructions regarding the sliding backing plate (also contains link to instructional video).
- Second, if the Latch is secure but misaligned, you can remove the two screw caps that reveal the screws that secure the door latch, and slightly loosen both screws, but do not fully remove, this will allow you to slightly maneuver the sliding backing plate into an aligned position with the automatic locking mechanism. Again, refer to the attached documents for useful notes that pertain to this procedure.
- If the screws are already stripped, and this is the problem, you may have to replace the entire backing plate, and you will need to contact me by email for sending you the repair kit , and instructions for replacing the sliding backing plate.

Rob Varga
Warranty Service Manager

Service Support



HABCO Manufacturing Inc. – Built to Perform. Crafted to Last.
501 Gordon Baker Road Toronto, ON, M2H 2S6
Toll Free: [800-448-0244](tel:800-448-0244) ext. 368, 367 or 365 | Fax: [416-491-6982](tel:416-491-6982)
servicesupport@habcomfg.com